

Technical Data:						
	Container Volume [L]	Container Ø [mm]	Power consumption [kVA]	Voltage [V/Hz]	Measurements W x D x H [mm]	Weight [kg]
TV 30	30	545x240x300	0,30	230/50	785x820x1220	240
TV 60	60	760x285x360	0,75	230/50	1000x780x1260	280
W 10	10	310	0,20	230/50	750x500x460	29
W 15	15	390	0,55	230/50	490x660x900	115
W 50	50	580	0,60	230/50	640x825x1155	165
W 100	100	770	0,80	230/50	870x920x1260	260







Trough vibrators
for smooth deburring or gentle polishing






Trough Vibrators TV





Options:

Manual separation with interchangeable sieves at an ergonomic working height integrated into the table or available as additional module
 Prepared for automatic separation TVsepa and TVsepa Mini
 Process water tank available as three-stage cascade for circuit



The working container can be divided up into 4 different chambers with optionally available partitions. Several workpieces can be finished separately without touching. Damage to sensitive workpieces is reliably avoided.

- Universal, even for large workpieces
- A rugged welded steel construction with low-wear polyurethane lining
- Time control with 10 programmes and digital display
- Speed control via frequency converter
- Finely adjustable dosing pump with compound level monitoring
- Control and dosing pump on a separate frame
- Easy to use
- Quick and gentle handling
- Long service life of the machine
- Good price/performance ratio





